



GH4000 device firmware update procedure

For firmware upgrade use Track Assistant software.

1. Connect device to computer via USB cable.
2. Open Track Assistant (do not connect GH to Track Assistant).
3. From Track Assistant menu bar, choose window named – Firmware.




4. Select firmware table from menu bar and choose Firmware version you need to install.



5. Switch GH in to FW (Firmware) update mode. To do it press and hold  green button and while holding it press reset button for 1-2sec. All buttons has to be released after the first and second LED will light up in green color.

Another way to switch GH to firmware update mode is to turn it off and while holding  button connect it to computer USB socket. When the LEDs turn on, release the button.



- 1 – Indicators (1 and 2 LED's has to light up)
- 2 – Keyboard button 1(green)
- 3 – Reset Button

Make sure that device is in the firmware update mode before starting an update. GH LEDs indication in FW update mode is shown in a picture below:



6. In a 'Select port' table select GH virtual port to which GH is connected to.

Step 1 - Select firmware

D:\GH\GH4000\Firmware\1.Base\GH4R_1.3.31\Firmware\GH4R_1.3.31.BIN

Step 2 - Select port


Select port: COM1

COM1
 COM3


Step 3 - Device flashing

If port is not available, then reconnect device USB cable and click on a 'Refresh' button. After select GH port. If the list contains more than one port, then look for GH port in 'Device manager>>Ports' window.

7. If the device is ready, then click on a 'Start' button to begin firmware installation.



8. After successful firmware update is recommended to delete device memory over Track Assistant>>Device configuration>>System>>Delete all data from device window. Look into picture bellow:



LEDs indication while updating FW:

	 Battery	 GSM	 GPS/Alarm
Device is ready for firmware update			
Device is not ready for firmware update, USB data cable error			
Firmware update in progress			
Firmware successfully updated			
Firmware error! It is deleted or damaged			

Types of errors and their solution

If firmware of the device has been damaged or removed, then it can be overwritten again.

	 Bateria	 GSM	 GPS/Pavojus
Firmware error! It is deleted or damaged			

In such a situation is needed to reconnected device USB cable. After reconnecting device cable and setting device in to FW update mode, firmware update can be started again.